



## SDV 430 PARTS LIST

ITEM NO.	DESCRIPTION	QTY
1	CASING	1
2	FRONT END PLATE	1
3	REAR END PLATE	1
4	FRONT END COVER	1
5	DRIVER SHAFT (A)	1
6	DRIVEN SHAFT (B)	1
7	SCREW	2
8	LOCKNUT	2
9	SETTING BOLT	2
10	PLATE GUIDE (A)	1
11	PLATE GUIDE (B)	1
12	PLATE GUIDE (C, D)	2
13	LIP SEAL	2
14	LANTERN RING	2
15	MECHANICAL SEAL STATOR (A)	2
16	MECHANICAL SEAL ROTOR (A)	2
17	BALL BEARING	2
18	BALL BEARING	1
19	ROLLER BEARING	2
20	BEARING HOLDER (A)	1
21	BEARING HOLDER (B)	1
22	BEARING STOPPER	2
23	LOCKNUT	2
24	LOCKWASHER	2
25	SLIP SLEEVE	2
26	LIP SEAL	6
27	LANTERN RING	2
28	LOCKNUT	2
29	LOCK WASHER	2
30	GREASE COVER	2
31	TIMING GEAR (A)	1
32	TIMING GEAR (B)	1
33	POWER LOCK	2
34	LOCKNUT	1
35	LOCK WASHER	1

ITEM NO.	DESCRIPTION	QTY
36	SEAL ADAPTER HOUSING	1
37	MECHANICAL SEAL STATOR (B)	1
38	MECHANICAL SEAL ROTOR (B)	1
39	SEAL ADAPTER HOUSING COVER	1
40	BLIND PLATE (A)	1
41	BLIND PLATE (B)	1
42	BLIND PLATE (C)	1
43	BLIND PLATE (D)	1
44	KEY	1
45	SIGHT GLASS ASSEMBLY	2
46	BLIND PLATE GASKET (A)	1
47	BLIND PLATE GASKET (B)	1
48	BLIND PLATE GASKET (C)	1
49	BLIND PLATE GASKET (D)	1
50	SPACER	2
51	SETTING BOLT	4
52	AIR FILTER	1
53	DRAIN VALVE	2
54	EYE BOLT	3
55	STUD BOLT	8
56	HEXA BOLT	8
57	NIPPLE	2
58	SLINGER, REAR END PLATE	2
59	MESH FILTER	2
60	AIR VENT	1
61	DOWEL PIN	2
62	DOWEL PIN	4
63	O-RING	2
64	O-RING	1
65	O-RING	1
66	O-RING	1
67	O-RING	1
68	O-RING	2
69	O-RING	2
70	O-RING	1